

## AIR CONDITION

Item	Qty	Article no	Description	Supplementary data
000	1	288 1085-801	AIR CONDITION	
001	1	288 1085-001	. COVER	
002	1	288 1085-002	. MACHINE HOUSING	
003	1	288 1085-003	. EVAPORATOR HOUSING	
004	1	288 1085-004	. RECIEVER	
005	2	288 1085-005	. CONDENSER	
006	1	288 1085-006	. COMPRESSOR	
007	1	288 1085-007	. FILTER DRIER	
008	2	288 1085-008	. CONDENSER FAN ✓	
009	1	288 1085-009	. EVAPORATOR	
010	1	288 1085-010	. HEATING ELEMENT	
011	1	288 1085-011	. OVERHEATING SENSOR	
012	2	288 1085-012	. EVAPORATOR FAN	
013	1	288 1085-013	. SIGHT GLASS	
014	1	288 1085-014	. EXPANSION VALVE	
015	1	288 1085-015	. STARTING DEVICE	
016	1	288 1085-016	. THERMOSTAT ✓	
017	1	288 1085-017	. FUNCTION SELECTOR	
018	1	288 1085-018	. PILOT LAMP COMPRESSOR	
019	1	288 1085-019	. PILOT LAMP HEATING ELEMENT	
020	1	288 1085-020	. COMPRESSOR CONTACTOR	
021	1	288 1085-021	. AUX. RELAY DEHUM.	Also order item 022.
022	1	1223806	. SOCKET FOR RELAY	Also order item 021.